



INSTALLATION INSTRUCTIONS

1. Because **UltraTouch** is compressed for shipping purposes, give it a quick shake prior to installing. This will help accelerate the natural rebounding properties of the fibers.
2. Install **UltraTouch** between the studs by simply fitting each batt firmly into place. If building codes require a vapor barrier, it should be applied towards the living area. Use a carpet installer's pad knife to cut or your hands to easily tear (**UltraTouch does not itch**) the insulation and fit snugly between the framing. For
3. Cut or tear the insulation to fit snugly around obstructions such as plumbing, vent lines, and electrical boxes. Use any left over pieces to fill small openings around windows and doors.
4. Either a 4-mil or 6-mil poly-vapor retarder will need to be installed if this is an exterior wall. The interior finish material such as drywall should be installed as soon as the insulation is placed.

Helpful Hint: Did you know that a continuous poly-vapor retarder is a more effective vapor retarder than individual kraft faced batts? It also requires less labor!

Fire Hazard Warning

1. *To avoid fire, do not place insulation within 3 inches of light fixtures or similar electrical fixtures.*
2. *Do not place insulation in air spaces around surrounding metal chimneys, fireplaces, or flues.*